

Step three

The Perfect Finish



Apply the Corner Tape

- remove the clear film
- fill the gap
- use the forming tool
- remove the tape

LOOK!
NO FINGER
A PERFECT RESULT

Easy to use



1 Peel backing paper

Peel back the white backing paper for approx. 30cm revealing the metal tape. Always start with masking the corners. See Tips & Tricks.



2 Apply revealed tape to wall

Start with overlapping the pre-masked corners. Place the roll flush against the wall, crease in the corner. Attach the CornerTape to the wall.



3 The CornerTape grip

Place your thumb inside the roll holding the roll against the surface, and your index finger on the side of the roll. Remove the backing paper whilst rolling along the corner.



4 Unfold tape

Place the forming tool in the corner preventing dislocation of the tape and unfold to the opposite wall. See Tips & Tricks.



5 Remove foil

Remove the plastic film. Only the silver tape should be left on each side. Apply silicone in the preset gap.



6 Use forming tool

Smooth the whole joint using the enclosed joint former. Keep the former at a fixed angle, slightly downwards.

REMOVE TAPES:
A PERFECT FINISH!

Tips & Tricks



3-way corner & 2-way corner

All corners must be masked before doing the long runs. Simply cut 3 pieces of CornerTape. Start in one corner approx. 1 cm from the gap. Remove the clear film. Repeat on the other sides. Then mask up the long runs and overlap onto the pre-masked corner. For a 2-way corner, don't remove the clear film from the 3rd side of the joint, this will then block the sealant.



Removing metal tape

If you are struggling to remove the metal tape, use the back of the clear plastic film. Attach the film to the metal tape and pull gently.



Struggling to remove the clear film?

Take the forming tool which is included and simply slide it in-between the clear and silver tapes. Start a little way down from the end of the tape, not at the very top.



Don't pull the tape out of the joint

Take the forming tool and slide in-between the two tapes and press it right into the corner. Now just fold over the tape and lightly press the other half of it down. Don't run the tool down the joint, but repeat these two steps every 50 cm.

Instructions

NO FINGER
needed



For perfect
silicone
joints

Step one

Easy Removal



Pull, push or scrape off the old silicone

Also available in steel for frequent use and tougher jobs.

PROFESSIONAL



The Residue Remover easily removes the final residue from uneven surfaces.

Step two

Simple Preparation



**Cheap
life insurance
for your joint**
(double the lifetime)

Disinfects and de-greases

- Kills all bacteria and leaves the surface perfectly prepared
- Ensures great adhesion of your new sealant